


Home Center Introduction


Terncy Home Center is the hub of Xiaoyan's ecosystem. With other accessories, it supports remote connection, intrusion detection, lighting automation, power consumption management, environmental perception, etc. through Terncy app via ZigBee 3.0 wireless protocol.



1

Download and Install App


Download Terncy app from application markets or scan the QR code below. Follow the direction in the app to connect your devices properly.



2

Connect Home Center to network


Connect the power adapter to Home Center and plug it to mains socket.



3



Connect Home Center to network

Connect Home Center's LAN port to a router with network cable. Make sure the cell phone for control connects to the same network.



4


Setup Home Center in Terncy App



1. During first start-up of Terncy app, the app will automatically detect Home Center and list it on screen.
2. Select your Home Center from the list, or tap "Begin scanning" to scan the QR code on the bottom of the Home Center.
3. Tap "Add" button to complete setup.

5

Setup Additional Home Center in Terncy App



1. Tap "≡" button on the top left corner in Terncy app. Tap "Add Home Center" on the sidebar.
 2. Select your Home Center from the list, or tap "Begin scanning" to scan the QR code on the bottom of the Home Center.
 3. Tap "Add" button to complete setup.
- * If the Home Center has been connected by another user, an approval will be needed.

6



WeChat official account

Contact Us

Online Support: <http://www.xiaoyan.io/service>

E-mail: support@xiaoyan.io

Manufacturer: Shanghai Xiaoyan Technology Co., Ltd.

Address: Room 503, Building B, NO.2305, Zuchongzhi Road,
Shanghai, China

Setup Home Center in HomeKit



1. Tap "+" on the top right corner in Home app of iOS.
2. Tap "Add Accessory" on the menu.
3. Scan the HomeKit setup code as prompted onscreen.
4. Select your Home Center and follow the directions to complete setup.

Indicator Light State




Indicator Light

State	Solid green	Working properly
	Yellow LED flashing	Connecting to network
	Solid yellow	About to reset to factory default settings
	Yellow, green and blue LED flashing in turn	Updating firmware

Reset to Factory Default

Press and hold the reset button for 5 seconds until the LED glows yellow. Then entire resetting process will take about 30 seconds.



Reset Button

Notes

1. Ensure the Home Center and the cell phone for control are on the same network
2. Each Home Center supports connecting up to around 50 devices.
3. Do not soak or wash your devices.

Controlling this HomeKit-enabled accessory automatically and away from home requires an Apple TV with tvOS 10.2 or later or an iPad with iOS 10.3 or later set up as a home hub.

Communication between iPhone, iPad, or iPod touch and the HomeKit-enabled Home Center is secured by HomeKit technology.



Manual of Terncy Home Center



Warranty Card

Xiaoyan's after-sales service includes:

Xiaoyan Tech shall remove any physical defects inherent in the device which are listed on the warranty card, free of charge, by replacing (at the sole discretion of Xiaoyan Tech) the defective device within the period of 15 days from the date of reception by the consumer, and by repairing the defective components of the device within the period of 12 months from the date of reception by the consumer.

*** The warranties may be varied in different countries and regions.**

The Warranty Applies to:

1. surface damages resulting from mishandling during transport or defects inherent in material or structure of the products;
2. failure of the buttons or indicator lights;
3. failure of wireless communication.

The Warranty Does Not Apply:

1. when the warranty period expired;
2. to damages resulting from repairing and introducing alterations by unauthorized persons;
3. to damages caused by using accessories not recommended by the manufacturer;
4. to damages resulting from other irresistible causes.